


DS-DHP-MC1B1-2
(Loto)
PHP-MC1B1-2

R01: D:Q001, 2, 3, 4, 5, 6, 7, 8
R02: Empty
R03: Spare, Spare, D:Q014, 15, 16, 17, 20, 21
R04: Prac30 - D:Q001, 2, 3, 4
Prac31 - D:Q005, 6, 7, 8
Prac32 - D:Q012, 13, 14, 15

R04: Prac33 - D:Q016, 17, 20, 21
Prac34 - D:Q022, 23, 24
Prac35 - D:Q025, V003, H005
R05: 4 Ch Buffer card, D:Q023, 24, 26, Water Flow
D:Q024A, 24B

R06: D:Q022, 023
R07: D:Q012, 13, Q025A, 25B



R10: Safety
R11: Console
R12: 204 Patch Panel
R13: Swic Chassis
PWC011, 14, 19, 21, 25
2 Motor Chassis
R14: Droeges
R15: Empty
R16:

R20: Correctors
D:HT000, VT005, HT005, HT011
D:VT011, VT017, VT013, HT019
D:HT020, VT023, HT024
R21: VME
D:CSMC1 - Bulk PS
R22: Scope
R23: Empty
R24: SWIC Contollers, PWC933, PWCDA1
3 Moter Chassis
R25: SWIC Contollers
PWC919, 922, 924, 926, 927
PWC930, 932, 935, 836
R26: Empty
R27: BLMs
R28/R29: Empty
FDS
R30/R31: Empty
R32:
R33: Empty
R34:
R35 Pracs: 46, 47, 48, 49
R36:
R37: Empty
R38: Empty

MC-1 Power Supply Room